



Safety RCD Adaptor Operating Instructions

TEST PROCEDURE

STEP ONE

1. Insert your RCD Adaptor into a fixed wall mounted 13 amp mains supply socket.
2. Switch on power at socket, if applicable.
3. Indicator is clear (white).

STEP TWO

1. Press button down (past the first click) as far as it will go - and release. Red bars will appear in the indicator window.

STEP TWO continued.

2. Lightly press button until first click and release. Indicator window will turn clear (white). If red bars do not disappear DO NOT USE and return to place of purchase with till receipt.
3. You have now tested your RCD Adaptor.

OPERATING INSTRUCTIONS

Plug appliance into RCD Adaptor.
Press button again as far as it will go and release. Red bars will appear. Ready for use.

NOTE:

Should your RCD then instantly trip (the indicator window turns clear/white) unplug from socket and have the appliance checked immediately for a potential earth leakage by a qualified electrician. If the RCD Adaptor is disconnected from the power supply, it will require resetting - Repeat the test procedure from step one.

IMPORTANT - FOR YOUR PROTECTION

Electricity is dangerous and an RCD must not be used as a substitute for normal precautionary measures. Always unplug from mains supply when not in use.

Do not allow children to tamper with electrical devices. Should your RCD Adaptor repeatedly trip with an appliance connected or fail to trip when tested, seek advice immediately from a qualified electrician, or return to place of purchase.

This device does not protect against electric shock due to contact with both conductors or a fault in the wiring supplying this device.

This RCD Adaptor has been designed for storage and use between -5°C and 40°C, and at an altitude no greater than 2000m above sea level.

Care must be taken not to subject your adaptor to abnormal pollution by smoke, chemicals or flammable fumes, salt-laden spray, prolonged periods of high humidity, immersion, repeated dropping or other abnormal conditions.